



Key 0-9
shows time
Key #
shows date

FEATURES :

- 12/24 hour system
- Date

How to see Time in 12-hour system :

- Press any number key 0 to 9 to see Time
e.g. 0 , 9 , 1 , 5 means 09 : 15.



How to see Time in 24-hour system :

- Press any number key 0 to 9 to see Time
e.g. 2 , 1 , 1 , 5 means 21 : 15.



How to change between 12 or 24-Hour System:

- Press and hold key "0" & "8" for about 2 seconds will change the 12/24 hour system.



blinking 1 , 2 , 1 , 2 ,
1 , 2 = now the time
is 12 hour system.



blinking 2 , 4 , 2 , 4 ,
2 , 4 = now the time
is 24 hour system.

How to see Date :

- Press * key to see Date : * light on = DATE display
e.g. 0 , 7 , 2 , 4 means July 24th.



How to set the time in 24-Hour System:

- Press and hold Key * and 9 for about 2 seconds, it will go to SET Time Mode. (the * light will be blinking).
- Press 4 digits, the first 2 digits will be Hours and the 3rd and 4th digits will be Minutes.
e.g. press 2359 = 23:59, i.e. 23 hours 59 minutes.
- Press Key * as "enter" to jump to Date Set (you will see the blinking of * light is quicker. This is now at the Date Set mode).
- Press 4 digits, the first 2 digits will be Month and the 3rd and 4th digits will be Day-of-Month.
e.g. press 0915 = Sep 15th
- Press Key * as "enter" to finish Setting (you will see the * light is not blinking.)

- Black
- 35% Black
- White

How to set the time in 12-Hour System:

- Press and hold Key * and 9 for about 2 seconds, it will go to SET Time Mode. (the # light will be blinking).
- If AM, the morning time, press 4 digits, the first 2 digits will be Hours and the 3rd and 4th digits will be Minutes.
e.g. press 0823 = 08:23am
- If PM, the afternoon time, press "7" then press 4 more digits :
e.g. press 70823 = 08:23pm
- Press Key * as "enter" to jump to Date Set (you will see the blinking of * light is quicker. This is now at the Date Set mode).
- Press 4 digits, the first 2 digits will be Month and the 3rd and 4th digits will be Day-of-Month.
e.g. press 0915 = Sep 15th
- Press Key * as "enter" to finish Setting (you will see the * light is not blinking.)

*** Remarks :**

- During Hour/Minute/Month/Day setting, any wrong button pressed, you may repeat pressing the correct digits again. The watch will only record the last 4 digits you entered. After correctly pressed, then press Key * to the next step.
If the Time or Date entered are not a valid time nor date, the watch will neglect it and use your previous time/date.

To exit Time Setting Mode :

- To finish time setting, you may press Key * as "enter" or wait about 4 seconds without pressing key, it will automatically exit Time Setting mode.

Battery replacement

- One Lithium battery CR2032 provides the power to operate the lights
- If you notice your watch's light is getting dimmer, this is an indication that your battery needs to be replaced
- Do not wait until your watch stops functioning
- To avoid the possibility of damaging your product, we recommend that you send it to watch specialist to have the battery replaced and the case back properly sealed

Cautions

- Don't press buttons under water nor with excessive moisture on the product surface.
- Avoid long-term exposure to extreme temperature, direct sunlight. This can cause material coloring to fade or discoloration.
- Please avoid rough use or dropping this product. Do not use strong detergent, sprays or chemicals as this will dis-color the case or strap.
- To clean your watch use only soft cloth, moistened lightly.

Instruction Manual

