


# CLICK Turn Watch



Switch A - DIP  
Key B - Set Time  
Digit C - Mode of Watch

## How to see different modes :

- By turning the DIP, the digit ( C ) showing on the DIP represents the modes of the watch.



## 12-Hour Time :



## Day-of-Week :



## 24-Hour Time :




## Date :





## Seconds :



## Meter Time :



## How to read Meter Time :



## How to set the time :

- Press key B for 1 second will go into time setting mode.



## \* Remarks :

- During Time setting, only 24-hour mode will be display.
- Turn clockwise to increase digit, turn anti-clockwise to decrease digit.
- During Week setting, only English version will be displayed.
- Turn clockwise to move forward the day-of-week, turn anti-clockwise to move backward the day-of-week.



## To exit Time Setting Mode :

- To finish time setting, press Key B again or wait about 5 seconds, it will automatically exit time setting mode.

## Battery replacement

- One Lithium battery CR2032 provides the power to operate the lights
- If you notice your watch's light is getting dimmer, this is an indication that your battery needs to be replaced
- Do not wait until your watch stops functioning
- Weak or dead battery left in your product for an extended time may damage the movement
- To avoid the possibility of damaging your product, we recommend that you send it to watch specialist to have the battery replaced and the case back properly sealed

## Cautions

- Don't press buttons under water nor with excessive moisture on the product surface.
- Avoid long-term exposure to extreme temperature, direct sunlight. This can cause material coloring to fade or discoloration.
- Please avoid rough use or dropping this product. Do not use strong detergent, sprays or chemicals as this will dis-color the case or strap.
- To clean your watch use only soft cloth, moistened lightly.



## Instruction Manual



www.click-watch.com